

LOCATING UNDERGROUND UTILITIES

1-800-424-5555

CALL TWO WORKING DAYS BEFORE YOU DIG

The customer or contractor must call the Utilities Underground Location Center at least two full working days (48 hours) before trenching or excavating for underground service. One call to the Location Center notifies all pertinent utilities that a locate is required. Not all utilities are members of the 'One-Call' system. The Center will advise you which utilities will be notified. You will have to individually contact the utilities not listed. Also define your own private water lines, gas/propane lines, underground feeder wires to outbuildings, sprinkler systems, etc.

Excavation must not begin until the locations of underground wires, cables, and pipes have been marked, or the utilities have informed the customer that they have no facilities in the area.

Any digging within 24 inches of location marks must be done by hand.

The color code for marking underground utilities is:

<u>Color</u>	<u>Underground Service</u>
RED	Electric
YELLOW	Gas, Oil, Steam
ORANGE	Telephone, Cable TV
BLUE	Water
PURPLE	Reclaimed water
GREEN	Sewer
PINK	Temporary survey marks
WHITE	Proposed excavation